

2.2.1. FREE WHEEL BODY ON THE SPEEDCITY™ WHEEL

Tools needed:

- 1 x 5 mm Allen wrench
- 1 x 12 mm Allen wrench
- 1 x 16 mm flat wrench
- Bearing pullers M40373
- Bearing pullers M40119 (part D, see page 40)
- 1 hub wrench M40123

- 1** Disassemble the axle kit and bearing kit by following procedures 2.1.1 and 2.3.1.
- 2** Insert the 12 mm Allen wrench from the side opposite the free wheel, through the guide ring supplied with the kit M40373 and loosen the free wheel body attachment nut ;
- 3** After cleaning the hub body, mount the free wheel body by tightening the attachment nut using a 12 mm Allen wrench and the guide ring supplied with the kit M40373. Torque: 45 - 60 Nm.
- 4** Mount the bearing kit and the axle kit as indicated in procedures 2.1.1 and 2.3.1.
- 5** Mount the wheel on the frame, tighten the quick release skewer and adjust the bearing free play using the hub wrench M40123.

