

## FRONT BEARING AND AXLE KIT FOR THE KSYRIUM® ELITE WHEEL

### Tools needed

- 1 x 5 mm Allen wrench
- 1 hub wrench M40123
- Bearing pullers M40373

- 1** Remove the fork support on the adjustment nut side. This is press fit on the end of the axle;
- 2** Insert a 5 mm Allen wrench on the opposite side of the adjustment nut and loosen the adjustment nut;
- 3** Remove the axle;
- 4** Drive out the bearings with the bearing pullers M40373;
- 5** Mount the new bearings using the bearing pullers M40373;
- 6** Mount the axle: insert the 5 mm Allen wrench in the axle and tighten the adjustment nut;
- 7** Clip the fork support back on;
- 8** Put the wheel back in place on the fork, tighten the quick release skewer and adjust the bearing free play using the hub wrench M40123.

